

For truck mounted couplers it is pretty much the same as body mounted couplers. The only difference is that the side of the coupler box cover needs to be roughed up so that the glue can stick to it and not to extend the air line back too far. If you do it may interfere with the turning radius of you car. See photo # 19.



Once the glue has set up you can go ahead and paint the metal air line to match the car color. Try not to get too much paint on the air hose itself. We want it to be nice and limber. I suggest using acrylic paint only for this so it doesn't do damage to the rubber itself. To color the magnet I highly recommend using a black sharpie as it dries quickly. If you use paint on the magnet you might have to let it dry over night before coupling together. If you don't let it dry completely the air hoses will be glued together. See the finished cars in photo #20



Also check out the how to video for more details on installing them.

Thanks for purchasing High Performance MagnaLock Brake